



# AT 330 OHV


## ALN 290W - 330W


- A2744 SHORT BLOCK ALN 330 STD / ELEST
- A2745 SHORT BLOCK ALN 330 VERT. ELEST
- A2747 SHORT BLOCK ALN 290 STD / ELEST

- A2749 SHORT BLOCK AT 330 OHV STD / ELEST




RICAMBI - SPARE PARTS - ERSATZTEILE - PIÈCES DETACHÉES - REPUESTOS






RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS




ALN - AT




RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS




ALN - AT



AT




ALN




RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS

AT




ALN




RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS




ALN








RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS




A.E. = Per Avv elettrico  
E.S. = For electric start

ALN - AT




-A2881 (ALN)


-A3306 (AT)



-A3296 (ALN)




-A2882 (AT 330)



RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS





ALN - AT




-A2984

- 691127 dia. 44 2A
- 691138 dia. 52 2A
- 691112 dia. 62 2A
- 691190 dia. 65 2A
- 691137 dia. 70 2A
- 691167 dia. 75 2A
- 691203 dia. 95 3A




-A2783




OIL WATCH

- A2964 (AT)
- A2967 (AT) A.E.-E.S.
- A2963 (ALN 330)
- A2966 (ALN 330) A.E.-E.S.
- A2962 (ALN 290)
- A2962 (ALN 290) A.E.-E.S.



A.E. = Per Avv elettrico  
E.S. = For electric start



CODICE	178123
DATA	06/02
N REVISIONE	5
EMESSO IL	10/96

RICAMBI - SPARE PARTS - ERSATZTEILE - PIECES DETACHEES - REPUESTOS



ALN

AT

