


82T16 2102986

TABLE OF CONTENTS

2102986 Guard&string head5	3
2102986 AL pipe4	5
2102986 hamess buckle& auxiliary handle3	7
2102986 handle2	9
2102986 rear housing1	11
2102986 exploded view-whole tool	13


2102986 Guard&string head5



Rendered by LeadVenture, Inc.

2102986 Guard&string head5


Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0104550-00	String Head Assembly		1
2	R0104395-00	String Head		1
3	R0104406-00	Cutting Assembly		1
4	R0104269-00	Cutting Blade		1
5	R0104551-00	Cutting Assembly		1



2102986 AL pipe4

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0208592-00	Pole Assembly		1
2	RA349013033	Harness assembly		1
3	R0208716-00	Conencting Piece Assembly		1
4	R0104396-00	Gearbox Assembly		1
5	R0208717-00	Blade Seat Assembly		1

2102986 hamess buckle& auxiliary handle3




Rendered by LeadVenture, Inc.

2102986 hamess buckle& auxiliary handle3

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0104392-00	Harness Buckle Assembly		1
2	R0104393-00	Auxiliary Handle Assembly		1

2102986 handle2




Rendered by LeadVenture, Inc.

2102986 handle2

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0104389-00	Handle Assembly		1
2	R0208609-00	Speed-control Switch		1
3	R0104390-00	Switch Trigger Assembly		1
4	R0104391-00	Panel Assembly		1

2102986 rear housingq1




Rendered by LeadVenture, Inc.

2102986 rear housing1

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0104387-00	Rear Housing Assembly		1
2	R0104249-00	Battery Pack Release Button Assembly		1
3	R0104247-00	Upper Shell Assembly		1
4	R0208598-00	Volute Housing Assembly		1
5	R0209304-00	Spring Seat Assembly		1
6	R0104388-00	Control Panel Assembly		1
7	R0208596-00	Air Inlet Guard Assembly		1
8	R0208595-00	Baseplate Assembly		1
9	R0208604-00	Motor Assembly		1

2102986 exploded view-whole tool



Rendered by LeadVenture, Inc.

2102986 exploded view-whole tool

Ref Number	Part Number	Part Description	Context Notes	Quantity
------------	-------------	------------------	---------------	----------