



PN4100 爆炸图

(09年09月新版) DESIGN BY PAINIER *[Signature]*

PN4100

Item No.	English Name	QT
GNNG4100-1	NUT	2
GNNG4100-2	MUFFLER ASSY	1
GNNG4100-3	GASKET-MUFFLER	1
GNNG4100-4	SCREW-MUFFLER	4
GNNG4100-5	SCREW	1
GNNG4100-6	CYLINDER	1
GNNG4100-7	SPARK PLUG	1
GNNG4100-8	GASKET-CYLINDER	1
GNNG4100-9	PISTON RING	2
GNNG4100-10	RING-SNAP	2
GNNG4100-11	PISTON	1
GNNG4100-12	PIN-PISTON	1
GNNG4100-13	BOOT-INTAKE	1
GNNG4100-14	SPRING-INTAKE	1
GNNG4100-15	FLANGE-CARBURETOR	1
GNNG4100-16	CARBURETOR	1
GNNG4100-17	SCREW	1
GNNG4100-18	GROMMET-INNER	1
GNNG4100-19	SCREW	1
GNNG4100-20	SCREW	4
GNNG4100-21		1
GNNG4100-22	COVER-TOP	1
GNNG4100-23	GROMMET-CHOKE KNOB	1
GNNG4100-24	CHOKE KNOB	1
GNNG4100-26		1
GNNG4100-27	AIR FILTER	1
GNNG4100-28	COVER-AIR FILTER	1
GNNG4100-29	KNOB-AIR FILTER	1
GNNG4100-30	HOLDING SUPPORT	1
GNNG4100-31	SPRING-CLUTCH	1
GNNG4100-32	HOOF BLOCK	3
GNNG4100-33	WASHER-CLUTCH	1
GNNG4100-34	DRUM-CLUTCH	1

PN4100

Item No.	English Name	QT
GNNG4100-35	NEEDLE BEARING BALL CLUTCH	1
GNNG4100-36	GEAR WORM	1
GNNG4100-37	SCREW	1
GNNG4100-38	COVER-OIL PUMP	1
GNNG4100-39	SCREW	1
GNNG4100-40	OIL PUMP ASSY	1
GNNG4100-41	HOSE OIL	1
GNNG4100-42	WASHER	1
GNNG4100-43	SEAL OIL	1
GNNG4100-44	RING	1
GNNG4100-45	PIN-BRAKE	1
GNNG4100-46	CHAIN CATCHER	1
GNNG4100-47	STUD-BAR	1
GNNG4100-48		1
GNNG4100-49	SCREW	1
GNNG4100-50	RIGHT CRANK CASE	1
GNNG4100-51	PIN	3
GNNG4100-52	BEARING	
GNNG4100-53	WASHER-SPACER PISTON	1
GNNG4100-54	BEARING CRANKSHAFT	1
GNNG4100-55	CRANKSHAFT	1
GNNG4100-56	KEYWHEEL	1
GNNG4100-57	GASKET-CRANKCASE	1
GNNG4100-58	LEFT-CRANK CASE	1
GNNG4100-59	SEAL OIL	1
GNNG4100-60	FLYWEEL ASSY	1
GNNG4100-61	NUT	1
GNNG4100-62	BAFFLE-FAN	1
GNNG4100-63	SCREW	2
GNNG4100-64	SCREW	1
GNNG4100-65	HOUSING-STARTER	1
GNNG4100-66	STARTER SPRING	1
GNNG4100-67	COVER SPRING	1

PN4100

Item No.	English Name	QT
GNNG4100-68 (Y1)	PULLEY START (BIG)	1
GNNG4100-68 (Y2)	START SPRING	1
GNNG4100-68 (Y3)	PULLEY START (SMALL)	1
GNNG4100-69	WASHER	1
GNNG4100-70	SCREW	1
GNNG4100-71	GROMMET-ROPE	1
GNNG4100-72	WASHER	2
GNNG4100-73	SPRING-KICK BACK	1
GNNG4100-74	STARTER ROPE	1
GNNG4100-75	HANDLE-STARTER	1
GNNG4100-76	SCREW	1
GNNG4100-77	WIRE	1
GNNG4100-78	WIRE	1
GNNG4100-79	IGNITION ASSY	1
GNNG4100-80	GUIDE BUSH-ROPE	1
GNNG4100-81	SCREW	1
GNNG4100-82	SCREW	1
GNNG4100-83	HOSE	1
GNNG4100-84	FILTER	1
GNNG4100-85	PLUG-PAD	1
GNNG4100-86	SCREW	2
GNNG4100-87	RUBBER CUSHIONING (UPPER)	1
GNNG4100-88	SCREW	4
GNNG4100-89	LEFT CRANK CASE	1
GNNG4100-90	SCREW	1
GNNG4100-91	SPRING	1
GNNG4100-92	SCREW	1
GNNG4100-93		1
GNNG4100-94	PLUG-PAD	1
GNNG4100-95	RUBBER CUSHIONING	1
GNNG4100-96	ROD-THROTTLE	1
GNNG4100-97	PIN-TRIGGER	1
GNNG4100-98	SPRING-TRIGGER	1

PN4100

Item No.	English Name	QT
GNNG4100-99	TRIGGER	1
GNNG4100-100	FUEL CAP	1
GNNG4100-101	OIL CAP HOLDING	1
GNNG4100-102	WASHER-FUEL CAP	1
GNNG4100-103	WASHER-OIL CAP	1
GNNG4100-104	OIL CAP HOLDING	1
GNNG4100-105	SPRING	1
GNNG4100-106	SCREWM	1
GNNG4100-107	SCREWM	1
GNNG4100-108	SCREWM	1
GNNG4100-109	SWITCH STOP	1
GNNG4100-110	FUEL TANK	1
GNNG4100-111	Decorative Cover	1
GNNG4100-111-1	PRIMER BULB	
GNNG4100-112	LEVER-SAFETY TRIGGER	1
GNNG4100-113	COVER-REAR HANDLE	1
GNNG4100-114	BALANCE-SUPPORT	1
GNNG4100-115	BALANCE	1
GNNG4100-116	SCREW-CHAIN ADJUSTING	1
GNNG4100-117	CHAIN ADJUSTING	1
GNNG4100-118	PLATE-BAR	1
GNNG4100-119	SCREW	1
GNNG4100-120	SCREW	1
GNNG4100-121	SCREW	1
GNNG4100-122	FRONT HANDLE	1
GNNG4100-123		1
GNNG4100-124	SCREW	2
GNNG4100-125	PLATE-BAR	1
GNNG4100-126	BAND-BRAKE	1
GNNG4100-127	PIN	1
GNNG4100-128	FILTER	1
GNNG4100-129		1
GNNG4100-129-1	HOSE FUEL 1	1

PN4100

Item No.	English Name	QT
GNNG4100-129-2	HOSE FUEL 2	1
GNNG4100-129-3	OUTLET HOSE FUEL	1
GNNG4100-130	SUPPORT HOSE FUEL	1
GNNG4100-131	SCREW	3
GNNG4100-132	LEVERAGE-BRAKE	1
GNNG4100-133	SPRING-ACTUATION	1
GNNG4100-134	PLATE-BRAKE	1
GNNG4100-135	COVER BRAKE	1
GNNG4100-136	PIN	2
GNNG4100-137	COVER	1
GNNG4100-138	SPRING	1
GNNG4100-139	WASHER	1
GNNG4100-140	SPRING	1
GNNG4100-141	LEVERAGE-BRAKE	1
GNNG4100-142	BUSHING	1
GNNG4100-143	NUT	1
GNNG4100-144	WASHER	1
GNNG4100-145	SPRING	1
GNNG4100-146	LEVER-CHAIN BRAKE	1
GNNG4100-147	BUSHING	1
GNNG4100-148	PIN-LEVER	1
GNNG4100-149	NUT M8	2
GNNG4100-150	SPIKE	1
GNNG4100-151	SCREW	1
GNNG4100-152	GUIDE BAR	1
GNNG4100-153	CHAIN	1
GNNG4100-ZC1	CRANKSHAFT-CYLINDER ASSY	1
GNNG4100-ZC2	STARTER ASSY	1
GNNG4100-ZC3	DRUM ASSY CLUTCH	1
GNNG4100-ZC4	BRAKE HOUSING ASSY	1