



Item No	Part Name
GN-PH30B-1	Top cover
GN-PH30B-2	Reflector
GN-PH30B-3	Cone
GN-PH30B-4	Hearing tube 1200W/230V
GN-PH30B-5	Hearing tube 1800W/230V
GN-PH30B-6	
GN-PH30B-7	The famer of tube
GN-PH30B-8	Connecting
GN-PH30B-9	Reflector
GN-PH30B-10	Carrying cylinder
GN-PH30B-11	Connector
GN-PH30B-12	Screw
GN-PH30B-13	Grill
GN-PH30B-14	Top cover
GN-PH30B-15	Tip-over switch
GN-PH30B-16	Pull cord switch
GN-PH30B-17	Power indicator
GN-PH30B-18	
GN-PH30B-19	
GN-PH30B-20	String
GN-PH30B-21	Switch box
GN-PH30B-22	String
GN-PH30B-23	Up tube
GN-PH30B-24	locknut
GN-PH30B-25	Lock sleeve
GN-PH30B-26	
GN-PH30B-27	Middle tube
GN-PH30B-28	Down tube
GN-PH30B-29	
GN-PH30B-30	Power cord
GN-PH30B-31	Base
GN-PH30B-32	Heavy board

