


Part List

TC3080PL

- 1:Tray
- 2:Wheel
- 3:Protect Plate Under Tray
- 4:Slotware II
- 5:Connect Part
- 6:Slotware I



- 7:Metal Part II
- 8:Legs
- 9:Wheel axle
- 10:Walking Handle
- 11:Fixed Handle (Left)
- 12:Soft Handle Grip
- 13:Fixed Handle (Right)
- 14:Swivel Caster

