


REPAIR PARTS


ROTARY LAWN MOWER -- MODEL NO. BM38TA



REPAIR PARTS


ROTARY LAWN MOWER - - MODEL NO. BM38TA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	141912	Hex Washer Head Screw #10-24 x 1/2	21	152018	Adjuster Assembly (Left)
2	154049	Drive Cover	22	152019	Adjuster Assembly (Right)
3	701477	Push in Fastener	24	88080	Dust Cover
4	851980	Drive Pawl	25	67725	Washer
5	88043	Drive Pulley	26	88446	Wheel Bushing
6	12000030	Retaining Ring	27	750124	Wheel & Tire Assembly
7	54583	Screw 1/4-20 x 1/2	28	145212	Flanged Locknut
8	851947X004	Clutch Frame	29	85179	Retainer Clip
9	50962	Locknut 1/4-20	30	77400	Hubcap
10	702631X004	Clutch Lever	31	12000058	E-Ring
11	88067	Clutch Lever Spacer	32	137054	Pinion
12	750253	Locknut 5/16-18	33	63601	Locknut 1/4-20
13	72070504	Carriage Bolt 5/16-18 x 1/2	34	700537	Drive Shaft
14	74350424	Hex Head Screw 1/4-20 x 1-1/2	35	88082	Driven Pulley
15	88069	Spacer	36	111924X	Drive Belt
16	48160	Idler Assembly (Includes Key No. 17)	--	852000	"Clean Under" Decal (Drive Cover)
17	88576	Idler Spacer	Available accessories not included with mower:		
18	88517	Shoulder Bolt 5/16-18 x 1-3/8	--	MA36	Chute Deflector
19	88516	Idler Pulley			
20	87877	Selector Knob			



REPAIR PARTS

ROTARY MOWER MODEL NO. BM38TA



REPAIR PARTS

ROTARY MOWER MODEL NO. BM38TA

KEY NO.	PART NO.	DESCRIPTION
1	145793	Control Bar
2	145646X479	Upper Handle
3	157081X479	Lower Handle
4	132001	Rope Guide
5	63601	Locknut 1/4-20
6	131959	Handle Bolt
7	66426	Cable Tie
11	156577	Engine Zone Control Cable
12	158742	Drive Control
14	128638	Wing Nut
15	51793	Hairpin Cotter
17	145669	Drive Cable Guide
19	145854X479	Back Plate
20	700363X479	Side Baffle
21	146143X479	Foot Guard
23	147613	Rear Door Assembly Kit
25	151589X479	Handle Bracket Assembly (Left)
26	151588X479	Handle Bracket Assembly (Right)
27	150078	Screw 5/16-18 x 3/4
29	750085X007	Wheel Adjusting Bracket
30	146630	Spacer
32	700331X004	Selector Spring
33	87877	Selector Knob
34	145935X004	Axle Arm Assembly
35	62335	Belleville Washer
36	142748	Shoulder Bolt 3/8-16
37	148438	Wheel & Tire Assembly
38	83923	Flanged Locknut
40	77400	Hubcap
41	146694	Screw
42	53998	Flat Washer

KEY NO.	PART NO.	DESCRIPTION
43	54583	Hex Tapping Screw 1/4-20 x 1/2
44	133188X479	Discharge Baffle
45	850999	Hex Head Thread Rolling Screw 3/8-16 x 2
46	145494	Danger Decal
48	850988	Engine Spacer
49	850987	Engine Bushing
50	700063X479	Rear Baffle
51	701640X479	Front Baffle
52	162185	Housing Assembly (Incl. Ref. #46)
53	851084	Hex Head Bolt 3/8-24 x 1-3/8 Grd. 8
54	850263	Helical Lock Washer
55	851074	Hardened Washer
56	145106	20" Blade
57	851514	Blade Adapter
67	147270	Grass Bag
68	750532	Catcher Frame
70	-----	* Engine -Briggs & Stratton Model 98982
72	150050	Hex Washer Head Screw #10-16 x .50
73	128415	Pop Rivet
74	158755	Screw
75	751152	Nut
76	88652	Screw
77	751152	Nut
--	146983	Operator's Manual (English)
--	146984	Operator's Manual (French)
--	161924	Replacement Parts Manual (English/French)
--	800197	Noise Level Decal
--	145495	International Symbols Decal

